




Saver Powerbank 10000

Quick Guide

320-34B

Charge Powerbank





Saver Powerbank 10000

Item no. 320-34B

www.sandberg.world

info@sandberg.world

Sandberg A/S

Bregnerodvej 133D,


3460 Birkerød, Denmark

Made in China



NOTE: For optimal battery performance, we recommend fully discharging and recharging the powerbank at least once every three months.

Charge devices



Example of use